#### Battery Management System with advanced connectivity




Applica	tions		
	10S – 14S Lithium Battery Packs		
	50A cont. / 65A peak (in closed		
	compartments)		
	Certified in different Projects		
	according to CE, UN		
	NEW: Certified according to UL (with		
	redundant cell-voltage check and		
	chemical fuse)		
Interfac	ces / Connectivity		
	CAN: Automotive CAN-Bus		
	USB: Enable-Tool Interface		
	On/off input		
	Configurable LED-Display		
	Kill-switch input		
	12V-Output (1.7A, separate from		
	48V Ouput)		
Feature	25		
	NEW: Grid-capability: To connect up		
	to 50 battery-packs in parallel (e.g.		
	for storage applications)		
	Precise state of charge (SOC) and		
	state of health (SOH) calculation		
	Pre-Charge function		
	Current and voltage limits via CAN-		
	bus		
Safety	Features		
	Temperature monitoring for cells,		
	power-stage and controller		
	Redundant overcurrent protection		
	On-board fuses		

Main electrical parameters		
Number of Cells (Serial / Parallel)	-	10 145 / 30P
Max. Pack Voltage	V	60
Continuous Charge / Discharge Current	А	50
(No heatsink / in closed compartment)		
Peak Charge / Discharge Current	А	65 (8 minutes starting at 20°C)
(No heatsink / in closed compartment)		
Standby Current (Deepsleep)	μΑ	78
Idle Current (Active State)	mA	20
Powerstage topology	-	Combined Charge-/ Discharge
		terminal with back to back highside FET <sup>1</sup>
Switching the BMS output (combined cha	arge / discharg	ge terminal) on and off
To activate the combined charge / discharge termi	nal the BMS ther	re are several configurable ways to use
Long press on enable button	Mode 0	BMS output can be toggled with a
		push button long press. Any error
		event during discharge disables the
		output until the push button is
		pressed again
Key-mode (permanent connection from enable-	Mode 2	Use a key-switch or any other
signal to GND)		device that connectes the enable-
		signal with GND, to activate the
		BMS output
Connect a charger		BMS detects the charger and starts
		charging automatically
To enter the deepsleep		Press the push button for more
		then 3 seconds (super long press)
CAN-Bus remote control		Selectable Modes:
		- Charge (48V active)
		- Discharge (48V active)
		- Standby / 12V active
		- Deepsleep

FRIWO Gerätebau GmbH FRIWO Page 2/13

<sup>&</sup>lt;sup>1</sup> Interrupts charge and discharge current completely. Absolutly no current going in or out of the battery pack

LED indications on a LED-bar with 5 LEDs				
Push button short press		SOC is displayed for a few seconds		
During charging		LED stairs up to the current SOC,		
		then holds SOC indication for a few		
		seconds.		
On Error event		LEDs flashing to indicate error		
On entering deepsleep		LED stairs down to zero (goodbye)		
Mechanical Parameters				
Size	mm	152 x 63		
Height	mm	12.5		
Weight	Gramm	72		




<sup>&</sup>lt;sup>2</sup> Parameter list depends on predefined user-packages and use-case


#### **CAN-Bus Interface**

The CAN-bus interface is compliant with any standard automotive CAN-bus. The baudrate can be configured to from low-speed (125kbit/s) to high-speed (1000kbit/s). Messages are transmitted periodically (no remote request necessary).

This is an overview on the standard CAN-protocoll which is implemented by default. You can get a CAN matrix in Vector Informatik's standard file-formar (\*.dbc) on request.

Custom protocolls can be implemented on request.





Connector	Pin	Function	Additional Info
CON 11	1	LED1+	
(BM07B-SRSS-TB)	2	LED2+	
	3	LED3+	
	4	LED4+	
	5	LED5+	
	6	Push Button	
	7	GND	
CON 12	1	USB ID	
(BM08B-SRSS-TB)	2	USB DP	
	3	USB DM	
	4	USB 5V	
	5	USB GND	
	6	CAN High	
	7	GND	
	8	CAN LOW	

Cell Connection Terminals 10S Configuration <sup>3</sup>				
Connector	Pin / Color	Function	Additional Info	
CON 2	15	Cell 1- / GND	Setup for 10S (10 serial cells). Set	
(BM15B-SRSS-TB)	14	Cell 1+	switch 1 before connection CON 2	
	13	Cell 2+	and CON 1!	
	12	Cell 3+	100 E	
	11	Cell 4+		
	10	Cell 5+		
	9	Cell 6+		
	8	Cell 7+		
	7	Cell 8+		
	6	Cell 9+		
	5	Cell 10+		
	4	_		
	3	-		
	2	-	\$ \$55 mm (B) mm	
	1	-		
CON 2	2	-	Additional connection from TOP-cell	
(BM02B-SRSS-TB)	1	Cell 10+	to Pin1 to power the BMS	

 $<sup>^{\</sup>rm 3}$  Connect CON 2 first, then connect CON 1

Cell Connection Terminals 11S Configuration <sup>4</sup>				
Connector	Pin / Color	Function	Additional Info	
CON 2	15	Cell 1- / GND	Setup for 11S (11 serial cells). Set	
(BM15B-SRSS-TB)	14	Cell 1+	switch 1 before connection CON 2 and	
	13	Cell 2+	CON 1!	
	12	Cell 3+	\$ 10 c	
	11	Cell 4+		
	10	Cell 5+		
	9	Cell 6+		
	8	Cell 7+		
	7	Cell 8+		
	6	Cell 9+		
	5	Cell 10+		
	4	Cell 11+		
	3	-		
	2	-		
	1	-		
CON 2	2	-	Additional connection from TOP-cell	
(BM02B-SRSS-TB)	1	Cell 11+	to Pin1 to power the BMS	

FRIWO Gerätebau GmbH FRIWO Page 9/13

<sup>&</sup>lt;sup>4</sup> Connect CON 2 first, then connect CON 1

Cell Connection Terminals 12S Configuration⁵				
Connector	Pin / Color	Function	Additional Info	
CON 2	15	Cell 1- / GND	Setup for 12S (12 serial cells). Set	
(BM15B-SRSS-TB)	14	Cell 1+	switch 1 before connection CON 2	
	13	Cell 2+	and CON 1!	
	12	Cell 3+	13 13 ts   -   31	
	11	Cell 4+		
	10	Cell 5+	## ## ## ## ## ## ## ## ## ## ## ## ##	
	9	Cell 6+		
	8	Cell 7+		
	7	Cell 8+	1 1 2 4 1 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1	
	6	Cell 9+		
	5	Cell 10+		
	4	Cell 11+	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
	3	Cell 12+		
	2	-	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
	1	-		
CON 2	2	-	Additional connection from TOP-cell	
(BM02B-SRSS-TB)	1	Cell 12+	to Pin1 to power the BMS	

 $^{\rm 5}$  Connect CON 2 first, then connect CON 1

Cell Connection Terminals 13S Configuration <sup>6</sup>				
Connector	Pin / Color	Function	Additional Info	
CON 2	15	Cell 1- / GND	Setup for 13S (13 serial cells). Set	
(BM15B-SRSS-TB)	14	Cell 1+	switch 1 before connection CON 2	
	13	Cell 2+	and CON 1!	
	12	Cell 3+	10 10 4c	
	11	Cell 4+		
	10	Cell 5+	100 100 100 100 100 100 100 100 100 100	
	9	Cell 6+		
	8	Cell 7+		
	7	Cell 8+	2046	
	6	Cell 9+		
	5	Cell 10+		
	4	-	(銀) 48 / DE - DE	
	3	-	10 g 4c	
	2	Cell 11+	1 1 2 1 4 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
	1	Cell 12+		
CON 2	2	Cell 13+	Additional connection from TOP-cell	
(BM02B-SRSS-TB)	1	Cell 13+	to Pin1 to power the BMS	

FRIWO Gerätebau GmbH FRIWO Page 11/13

 $<sup>^{\</sup>rm 6}$  Connect CON 2 first, then connect CON 1

Cell Connection Terminals 14S Configuration <sup>7</sup>				
Connector	Pin / Color	Function	Additional Info	
CON 2	15	Cell 1- / GND	Setup for 14S (14 serial cells). Set	
(BM15B-SRSS-TB)	14	Cell 1+	switch 1 before connection CON 2 and	
	13	Cell 2+	CON 1!	
	12	Cell 3+	15 19 4 DE	
	11	Cell 4+		
	10	Cell 5+	100 AU 00 100 AU 00 100 AU 00	
	9	Cell 6+		
	8	Cell 7+		
	7	Cell 8+	2046	
	6	Cell 9+		
	5	Cell 10+		
	4	Cell 11+	報告   1   2   2   2   2   2   2   2   2   2	
	3	_	100 pg - 60 pg - 100	
	2	Cell 12+	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
	1	Cell 13+		
CON 2	2	Cell 14+	Additional connection from TOP-cell	
(BM02B-SRSS-TB)	1	Cell 14+	to Pin1 to power the BMS	

FRIWO Gerätebau GmbH FRIWO Page 12/13

 $<sup>^{\</sup>rm 7}$  Connect CON 2 first, then connect CON 1

Revision / History			
Version	Date	Change	
V1.6	20170327	Updated features	
V1.5	20150316	Images	
V1.4	20150316	Enable-tool description	
V1.3	20140601	Mechanical data	
V1.2	20140301	Electrial data	
V1.1	20130601	Initial document	